


Diagram 6.1  
Seismic Hazard



Legend

- Downtown Core Area
  - Zone 5: Very High Ground Failure Susceptibility
  - Zone 3: Moderate Ground Failure Susceptibility
  - Zone 4: High Ground Failure Susceptibility
  - Zone 2: Moderately Low Ground Failure Susceptibility
- Note: Areas within Zone 1: Low Ground Failure Susceptibility are off the map.

