MERRILL FIELD AIRPORT COMPASS ROSE

USE REQUIREMENTS AND PROCEEDURES March 3, 2010

Location: Latitude 61° 13' N Longitude 149° 51' W **Description:** Located off of the west end of Runway 7/25

(339 feet west of the west end of Runway 7/25 and 24 feet north of the runway center-line extended)

Magnetic Declination Observation Survey performed by Jack Townshend of USGS

Declination: 18 Degrees 40 minutes East

Date of Survey: October 27, 2007

→ Compass Rose will normally be available for use, with prior permission from Merrill Tower, subject to traffic and wind conditions.

Note: preferred time of usage is 7:00 am to 11:00 am daily or other times as coordinated with Merrill Tower.

- → During usage of the Compass Rose aircraft will be allowed to departure Runway 7 and full stop landings on Runway 25 (no over flights of the Compass Rose when in use).
- → Merrill Tower has the authority to cancel the requested use of the Compass Rose, with 10 minute notice to requestor, when wind conditions or air traffic require the full use of Runway 7/25.
- 1. Requester shall contact Merrill Tower a minimum of 1 hour prior to the requested time of use to allow time for coordination of air traffic:

Call Merrill Tower at 907-271-3121

- 2. Merrill Tower shall restrict traffic to no over flights of the Compass Rose when in use.
- 3. Requestor shall contact Merrill Tower on Ground frequency 121.7 to access the movement area and shall maintain continual radio communication with Merrill Tower during the use of the Compass Rose.
- 4. During the winter season snow is not routinely removed from the Compass Rose, check with the Airport Managers Office for surface conditions or for general questions concerning the Compass Rose:

Call Airport Managers Office at 907-343-6303